



CAUTION
Carefully check every surface
before using the machine.
Do not touch the nozzle.
If you touch the nozzle,
it may become very hot.
If you touch the nozzle,
it may become very hot.
If you touch the nozzle,
it may become very hot.

緊急停止

Roland

MODELA

POWER OFF
RETRACT
PAUSE
STOP